







Pos.	Code	Description
	5313210401	COVER
	7313217261	MOTOR ASSEMBLY
	5332108700	GASKET
	5332224100	MOTOR BELT GRINDER
	5332164700	RUNNER FRAME
	5332270300	EXPANSION CHAMBER LID
001	5513211311	COVER
002	5513211321	COVER
003	5332226300	MEASURING SPOON
004	5332278400	SIDE LEFT
005	7313224431	CLOSURE
006	5332278600	REAR PANEL
007	535714	STOPPER
008	5313211001	KNOB
009	5532145700	TANK
010	5332282000	COVER
011	<del>VN051</del>	SEE NOTE
012	7313212521	DOOR ASSY
013	5332278800	COVER
014	5332282600	FRONT PIECE
015	5332282400	SUPPORT
016	5332282500	SUPPORT
017	7313210381	PAN ASSY.
018	5332278300	SIDE RIGHT
019	6032120800	CUP PLATE
020	5332266600	FLOAT
021	<del>VH000</del>	SEE TECHNICAL INFORMATION
022	5332225000	BOTTOM
023	5332283900	TRAY
024	5132112500	SWITCH
025	5513212801	PIPETTE
026	5332259800	TUBE

Pos.	Code	Description
027	7313210411	COVER ASSEMBLY
028	9930000980	CARAFE ASSMBLY
029	5513212191	CONTROL BOARD
032	5132110500	MICROSWITCH
033	7332203600	COMPLETE GRINDER
034	5332144900	GASKET
035	6032105300	DIFFUSER
036	5332149100	O-RING
037	7332222900	INFUSION KIT
038	5032526800	WIRING TCO
039	5032526900	WIRING TCO
040	5332142200	SUPPORT
041	6132104700	SPRING
042	5132104100	MICROSWITCH
043	7332166600	SLIDER
044	5332142400	BUSH
045	5332142300	BUSH
046	5217100200	SENSOR NTC
047	5313217751	O-RING
048	5332213000	PIN
049	5332148400	VALVE
050	6132106900	SPRING
051	5332149100	O-RING
052	5332139200	FILTER
053	7313213901	GENERATOR
054	5213212381	BOARD
055	5132110500	MICROSWITCH
056	5213213971	HALL SENSOR
057	5332170600	BELT
058	7313226111	TRANSMISSION KIT
060	5313217701	O-RING D=3,85
061	5313216501	SUPPORT

Pos.	Code	Description
062	7313219431	VALVE
063	5232103200	PROTECTOR
064	5132106900	PUMP
065	534848	SUPPORT
066	5232104600	SENSOR REED
067	5213211931	POWER BOARD
068	5132104100	MICROSWITCH
069	6113210751	INSERT
070	6213210351	NUT
071	6213211521	BUSH
072	7013210391	CONNECTION
073	6113210741	CONNECTION
074	7313210661	VAPORIZER
075	5232105000	TCO
076	<del>V1000</del>	SEE TECHNICAL INFORMATION
077	5232105000	TCO
078	5213214671	FLOWMETER
079	5513213781	TUBE PTFE DI2-DE4 L=135 1BUSHE
080	536373	GASKET
081	5332196900	CONNECTION
082	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
083	6132101300	CLIP
084	5332239200	CONNECTOR
085	535692	O-RING
086	vt205651	FILTER
087	5513212881	TUBE PTFE DI2-DE4 L=270 2BUSHES
088	6113210021	SPRING
089	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
090	5332196800	CONNECTION
091	5213210181	SOLENOID VALVE
092	5513213791	TUBE PTFE DI2-DE4 L=335 1BUSHE
093	5213210171	SOLENOID VALVE

Pos.	Code	Description
095	5332196000	O-RING
096	5513214821	COUPLING CARAFE
097	5313217751	O-RING
098	5332177500	O-RING
100	9824800009	CLIP CLAMP
101	537407	CONNECTION
102	5332142600	HOOK
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW
116	5332139600	STOPPER
117	5332139500	VALVE
118	6132112200	SPRING
119	5332140300	PISTON
120	5332228500	SUPPORT